







## TEMPORARY SUSPENDED PLATFORM: KOMPLET + LEVA



**TRANSLATION OF THE ORIGINAL  
OPERATING INSTRUCTIONS MANUAL**  
This manual must be always available for the user.  
Additional copies may be obtained on request.



# Content

<b>1- Information for this manual:</b>	<b>5</b>
<b>2- Explanation of symbols used in this manual</b>	<b>5</b>
<b>3- General:</b>	<b>6</b>
3.1-Glosary and abbreviations used in this manual:	6
<b>4- Previous instructions and warnings:</b>	<b>7</b>
<b>5-Machine's description</b>	<b>9</b>
5.1-Area of application	9
5.2-TSP equipment	9
5.3-Main components	10
<b>-Setting up</b>	<b>14</b>
6.1-Efforts due to suspended loads	14
6.2-Configuración / dimensions	14
6.3-Assembly of the platform	20
6.4-Electric components	34
6.5-Introduction of the wire ropes in the platform	35
6.6-Running test	39
<b>7-Safety devices</b>	<b>45</b>
7.1-Integrated safety devices in manual hoist m.lift400	45
7.2-Integrated safety devices in electric hoist Leva	45
7.3-Integrated safety devices in electric cabinet	46
7.4-Fall arrest device system securchite600	47
7.5-Overload safety system in Leva	48
7.6-Upper and final limit switch in Leva	48
7.7-Phase controller	48
7.8-Emergency descent in Leva	49
7.9-Acoustic bleeper (Opctonal)	49
7.10-EN795 anchor point (optional)	49
<b>8-Operating the platform</b>	<b>51</b>
8.1-Preliminary checks	51
8.2-Rated capacity	53
8.3-Guiding the platform along the facade	56
8.4-Loading / unloading areas	56
8.5-Operating of the manual hoists m.lift400	56
8.6-Electric controls	58
8.7-No power emergency descent	59
8.8>Action in case of the fall arrest locking	60
8.9-Request for help with the acoustic bleeper (optional)	60
8.10-Moving the platform horizontally	61
8.11-Removing the wire ropes	63
8.12-Dismanting the platform	64
<b>9-Residual risks not covered by the design of the TSP</b>	<b>65</b>
<b>10-Troubleshooting</b>	<b>66</b>
<b>11-Maintenance</b>	<b>69</b>
11.1-Regular maintenance of the hoist m.lift400	70
11.2-Wire ropes	70
11.3-Elevator	71
11.4-Fall arrest device securichute	71
<b>12-Spare parts</b>	<b>72</b>
12.1-ACCESUS KOMPLET platform	72
12.2-Electric hoist Leva	73

12.3-Manual hoist m.lift400 .....	73
12.4-Electric cabinet .....	73
12.5-Fall arrest device securichute600 .....	73
12.6-Nameplates and labels .....	74
<b>13-Disposal and environmental protection.....</b>	<b>77</b>
<b>14-Model for Declaration of Conformity.....</b>	<b>78</b>
<b>15-Machine's historic.....</b>	<b>80</b>
15.1-Daily inspection report .....	81
15.2-Periodic inspection report .....	83

**DANGER!**

**Risk of wound and injuries due to fall of objects, failure, incorrect application and/or incorrect utilization,**

Read the whole operating instructions manual before the assembly and set up of the platform. Follow the instructions and procedures described in this manual in order to ensure a safety utilization of the equipment.

## 1- Information for this manual:

<b>Date of edition:</b>	<b>Manufacturer:</b>
12th Edition: 05/2025	<b>ACCESUS GROUP, S.L.</b> C/Energia 54 08940 Cornellà de Llobregat (Barcelona) Telf.: (+34) 93 475 17 73 www.accesus.es accesus@accesus.es
<b>Copyright:</b> All rights reserved.	

## 2- Explanation of symbols used in this manual

**DANGER!**

**Type and origin of danger**

Result: for example fatal or serious injuries.

-Solutions to eliminate the danger.

**IMPORTANT**

**Type and origin of danger**

Result: for example damage to machines or the environment.

-Solutions to eliminate any possibility of accidents

**NOTE**

Useful tips for optimum working. Instructions to operation / documentation in writing.

### 3- General:

This operating instructions manual is destined to the workers of the described machine. This operating instructions manual must be accessible to workers every time. Request more copies if it's necessary.

ACCESUS GROUP, S.L. saves the rights to modify the product described in this manual as a part of his continued improvement.

The clients can obtain more information about other ACCESUS products, demanding the documentation through address described at section 1 of this instructions manual. Please, check our website: [www.accesus.es](http://www.accesus.es).

#### 3.1-Glosary and abbreviations used in this manual:

<b>W.L.L.</b>	Working Load Limit.
<b>Electrician</b>	A professional worker who knows and has the correspondent and necessary qualification to know the risks and to avoid the danger that has an electrical environment.
<b>Worker</b>	A person who works professionally with the machine.
<b>TSP</b>	Temporary Suspended Platform.
<b>Exploiter</b>	The responsible for both the regulatory operation of the installation of the device and compliance with maintenance intervals and repair works.

## 4- Previous instructions and warnings:

• TSP (Temporary Suspended Platforms) is destined exclusively to a **professional use**. Must be destined only to qualified people with knowledge for set up and utilization. Workers must be prepared for works at heights. Workers must know and assimilate the Law of Labor Risk Prevention.

• The machine must be dismantled and stored at the end of the works.

• For a safety utilization the TSP requires at least 2 workers at the same time.

• This TSP can only be used by authorized staff with adequate formation and psychologically suitable. Keep out from unauthorized people.

• Before to install and use a TSP is essential, for safety and efficiency, **to read and assimilate all the contents of this manual** and proceed in agreement to this instructions. Likewise, before the service, it's important to read all the labels fixed on the machine.

• This manual must be conserved in good condition and always be available for all workers who use the TSP.

• In case of loss or deterioration of the labels, these must be replaced before the use of the machine. Request more copies of the instructions manual and labels if it's necessary.

• The responsible company must **apply the regulation of safety** relative to the assembly, utilization, maintenance and technical controls referred to all the equipment. The responsible company must give the instructions to the workers and verify his aptitudes.

• Before putting in service the platform, the person in charge of work, must verify and ensure the good condition of the TSP equipment.

• Don't use a TSP or an accessory (wire rope, suspension points, etc.) in bad condition. A **periodic control** of the machine by an authorized person is essential for safety. The maintenance not described in this manual must be realized by the manufacturer or by an authorized repairer.

• Don't use the equipment for other uses than the indicated in this manual. The manufacturer can't guarantee the product for other configurations not described in this manual. For other applications consult the manufacturer or a professional specialized technician before proceeding to assembly the equipment.

• **Don't use the TSP beyond the limits of utilization** described in this manual and the platform manufacturer, and specially don't exceed the rated load of use indicated in the labels.

• Apart from the instructions indicated in this manual, the manufacturer declines any responsibility for the consequences of a disassembly of the devices, modifications or manipulations, specially in case of substitution of the original pieces by others from different origin.

- This TSP has a life of 10 years. This duration is based on a utilization of the platform according to the instructions of this manual of 200 hours per year and with the condition that the annual reviews effect.
- A special care is needed by dangers that will appear when the TSP is over water, public areas or where it's not possible to get the platform down to a safe position.
- When planning the work, the climatic and wind characteristics of the site must be taken into account: in case of doubt, check the weather and wind conditions in the meteorological service before starting work.
- Don't use the TSP in severe conditions such as atmospheric extreme conditions, corrosive environments, magnetic fields, explosive atmospheres (ATEX), works under tension, works in low voltage network, etc.
- A special care is needed due to dangers derived from work with TSP in confined spaces.
- In the vicinity of the winch it is necessary to use hearing protection.
- Don't use the TSP for loads which can generate dangerous situations (for example: molten metal, acids, radioactive materials, etc.)
- For platforms employed at heights upper than 40 m and exposed to winds over 50km / h, they must limit the lateral movements by a guide system, composed by anchorages each 20m.
- A special care is needed by dangers that will appear when the loads are manipulated.
- **In some countries of the European Union is obligatory an inspection before the putting in service of a new work. This control must be realized by an authorized organism.**
- **To cover risks arising from misuse, it is necessary the use of personal protective equipment (PPE) fall arrest by operators. See section 8.1 of this instructions manual.**

**IMPORTANT:**

If you entrust this equipment to subcontracted personnel you have to apply and check his obligations about safety at work, specially for verifications and tests before the putting in service.

**RISK ASSESSMENT:**

According to 92/57/CEE, each contractor shall prepare a **Safety and Health** plan at work which analyses, studies, develops and supplements the provisions contained in the study or basic study, based on their own system of execution of the work.

## 5-Machine's description

### 5.1-Area of application

The machine described in this manual is destined to be used temporary for inspection and maintenance works for vertical surfaces (persons elevation and tools included).

The platform remains excluded for:

- Temporary suspended platforms equipped with elevators with a maximum capacity of use exceeding 500kg.
- Temporary suspended platforms suspended by 3 points or more.
- Suspended platforms designed for permanent installation in buildings.
- Platforms suspended from the hook of a crane.
- Explosive atmospheres (ATEX).

### 5.2-TSP equipment

The equipment described in this manual is composed by an aluminium suspended platform equipped with two m.lift400 manual hoist or Leva powered hoist (with fall arrest device securichute600), suspended by steel wire ropes.

ACCESUS can also provide or advise in choosing of the most suitable roof beam or suspension structure. If you have a roof beam, ACCESUS can study your case and document it so you can use the aluminium suspended scaffold safely and documents in order.

The limit of the equipment described in this manual are the hooks of work and safety wire ropes.

If this equipment does not adapt to your needs, ACCESUS can advise in the correct choice of a suspended scaffold and/or suspension structure for your specific case. If it's necessary we can design a bespoke solution for you.


The TSP includes all the safety devices to make a temporary suspended access installation covered by the declaration of conformity made by the manufacturer and according to the Machine Directive.

### 5.3-Main components

The main components are:

**Suspended platform Accesus KOMPLET manufactured in aluminum and steel (with end panels)**, composed by:


- 1-Manual hoist **m.lift400** or electric hoist **Leva**. (2 units),
- 2-Fall arrest device integrated in en **m.lift400** or **securichute600** in case of **Leva** (2 units),
- 3-Electric cabinet in case of **Leva** (1 unit),
- 4-End panel (2 units),
- 5-Handrails,
- 6-Floor panels,
- 7-Elevator anchorage (2 units),
- 8-Support wheels (2 units.),
- 9-Works and safety wire ropes (4 units),
- 10-Side panels,
- 11-Connection stirrup.



The main components are:

**Suspended platform Accesus KOMPLET manufactured in aluminium and steel (with pass-through stirrup)**, composed by:


- 1-Manual hoist **m.lift400** or electric hoist **Leva**. (2 units),
- 2-Fall arrest device integrated in en **m.lift400** or **securichute600** in case of **Leva** (2 units),
- 3-Electric cabinet in case of **Leva** (1 unit),
- 4-End panel (2 units),
- 5-Handrails,
- 6-Floor panels,
- 7-Elevator anchorage (2 units),
- 8-Support wheels (2 units.),
- 9-Works and safety wire ropes (4 units),
- 10-Side panels,
- 11-Connection stirrup.
- 12-Pass-through stirrup (2 units).



The main components are:

Accesus KOMPLET CABIN suspended platform in aluminium and steel (with passing lyre), composed by:

- 1-Lifting device Cam (1 unit.),
- 2-Safety device integrated in ATURA (1 unit.),
- 3-Electric cabinet (1 unit.),
- 4-Step lyre (1 pc.),
- 5-Handrails,
- 6-Floor,
- 7-Motor anchor (1 unit.),
- 8-Suspension and safety cables (2 pcs.),
- 9-Side supports,
- 10-Union lira,
- 12-Extreme Lira.






**Roof beam of suspension structure,** the suspended scaffold Accesus must be suspended by structure or roof beam that meets the specifications described in the UNE-EN1808 and the European Directive 2006/42/EC.

A qualified person must perform the calculations or load test and be the responsible of the structure's capacity to support the efforts due to the suspended loads.

ACCESUS recommends a test load for your special suspension structure in order to verify that the anchorage points are correct. ACCESUS proposes this service and gives you a certification of the load test if you need.

Below are described some typical configurations.



## 6-Setting up

### 6.1-Efforts due to suspended loads

The vertical reaction to the hooks of the wire ropes (work and safety) of the suspended scaffold Accesus depending on the elevator is:

	<b>m.lift400</b>	<b>Leva</b>
Reaction factored on hook (R)	1200 kg	1500 kg

According to the UNE-EN 1808 standard, the anchor point must support the greater reaction with a safety factor of 3.

ACCESUS recommends the use of standard suspensions such as the Brakoo system, or the rest of the ACCESUS suspension range.

A qualified person must perform the calculations or load test and be the responsible of the structure's capacity to support the efforts due to the suspended loads.


ACCESUS recommends a test load for your special suspension structure in order to verify that the anchorage points are correct. ACCESUS proposes this service and gives you a certification of the load test.




### 6.2-Configuración / dimensions


The suspended scaffold Accesus is a team composed of modular elements of 2m and 3m of length which can be combined in different configurations. These configurations range until 21m.







The following tables describe the configurations, load capacity and dead weight.


LOAD CAPACITY










With 1 elevator		Platform with carrier end panels			
Elevator	Platform length (m)	0,5	1	1,5	2
Leva	 Weight load capacity (kg)	120	240	240	120
	 Number of people	1	2	2	1
	 Dead weight (kg)	170	180	190	200

**LOAD CAPACITY**


With 2 elevators		Platform with carrier end panels													
Elevator	Platform length (m)	2	3	4	5	6	7	8	9	10	11	12	13	14	15
m.lift® 400	 Weight load capacity (kg)	250	380	510	560	450	390	360	-	-	-	-	-	-	-
	 Number of people	2	3	4	5	4	3	3	-	-	-	-	-	-	-
	 Dead weight (kg)	165	185	215	235	250	275	295	-	-	-	-	-	-	-
Leva	 Weight load capacity (kg)	380	570	650	630	610	580	560	530	510	410	330	260	210	170
	 Number of people	2	3	4	5	6	6	6	5	5	4	3	2	1	1
	 Dead weight (kg)	240	260	290	310	325	350	370	385	415	435	450	480	505	530

**LOAD CAPACITY**


With 2 elevators		Platform with carrier pass-through stirrup																		
Elevator	Total platform length L (m)	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
	Maximum distance between stirrup L1(m)	2	3	4	5	6	7	8	9	10	11	12	12	12	12	12	13	14	15	16
	Cantilever max L2(m)	0,5	0,5	1	1	1,5	1,5	2	2	2	2	3	3	3	3	3	3	3	3	3
	 Cantilever Weight load capacity L2 (kg)	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120
m.lift® 400	 Weight load capacity (cantilever included) L (kg)	380	450	450	450	390	360	-	-	-	-	-	-	-	-	-	-	-	-	-
	 Number of people	3	4	4	4	3	3	-	-	-	-	-	-	-	-	-	-	-	-	-
	 Dead weight (kg)	285	315	335	350	375	395	-	-	-	-	-	-	-	-	-	-	-	-	-
Leva	 Weight load capacity (cantilever included) L (kg)	570	620	590	570	540	520	500	470	450	410	400	370	340	320	300	280	240	190	150
	 Number of people	3	4	5	6	5	5	5	4	4	4	4	3	3	3	2	2	2	1	1
	 Dead weight (kg)	360	390	410	425	450	470	485	515	535	550	580	605	630	655	675	700	730	755	775

The **maximum** overrun (L2) authorized is 3m.

**COMPOSITION**

Platform with carrier end panels															
Elements description	Platform length (m)	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	Floor panel of 2m	1	0	2	1	0	2	1	0	2	1	0	2	1	0
	Floor panel of 3m	0	1	0	1	2	1	2	3	2	3	4	3	4	5
	Connection stirrup	0	0	1	1	1	2	2	2	3	3	3	4	4	4
	End panel	2	2	2	2	2	2	2	2	2	2	2	2	2	2
	Side panel of 2m	2	0	4	2	0	4	2	0	4	2	0	4	2	0
	Side panel of 3m	0	2	0	2	4	2	4	6	4	6	8	6	8	10
	Handrail of 2m	2	0	4	2	0	4	2	0	4	2	0	4	2	0
	Handrail of 3m	0	2	0	2	4	2	4	6	4	6	8	6	8	10
	Fasteners	12	12	24	24	24	36	36	36	48	48	48	60	60	60

Platform with carrier pass-through stirrup																				
Elements description	Platform length (m)	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
	Floor panel of 2m	0	2	1	0	2	1	0	2	1	0	2	1	0	2	1	0	2	1	0
	Floor panel of 3m	1	0	1	2	1	2	3	2	3	4	3	4	5	4	5	6	5	6	7
	Connection stirrup	0	1	1	1	2	2	2	3	3	3	4	4	4	5	5	5	6	6	6
	Pass-through stirrup	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
	End panel	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
	Side panel of 2m	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0
	Side panel of 3m	2	0	2	4	2	4	6	4	6	8	6	8	10	8	10	12	10	12	14
	Handrail of 2m	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0
	Handrail of 3m	2	0	2	4	2	4	6	4	6	8	6	8	10	8	10	12	10	12	14
	Fasteners	12	24	24	24	36	36	36	48	48	48	60	60	60	72	72	72	84	84	84

		Cabin				Platform with carrier pass-through stirrup																		
Description of elements	Platform length (m)	0,5	1	1,5	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
	Floor panel of 0,5m	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Floor panel of 1m	0	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Floor panel of 2m	0	0	0	1	0	2	1	0	2	1	0	2	1	0	2	1	0	2	1	0	2	1	0
	Floor panel of 3m	0	0	0	0	1	0	1	2	1	2	3	2	3	4	3	4	5	4	5	6	5	6	7
	Con- nection stirrup	0	0	0	0	0	1	1	1	2	2	2	3	3	3	4	4	4	5	5	5	6	6	6
	Pass- through stirrup	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
	End panel	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
	Side panel of 0,5m	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Side panel of 1m	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Side panel of 2m	0	0	0	1	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0
	Side panel of 3m	0	0	0	0	2	0	2	4	2	4	6	4	6	8	6	8	10	8	10	12	10	12	14
	Handrail of 0,5m	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Handrail of 1m	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Handrail of 2m	0	0	0	1	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0	4	2	0
	Handrail of 3m	0	0	0	0	2	0	2	4	2	4	6	4	6	8	6	8	10	8	10	12	10	12	14
	Fasten- ers	12	12	12	12	12	24	24	24	36	36	36	48	48	48	60	60	60	72	72	72	84	84	84

The heaviest components are the elevators and the passage liras, which weigh 50kg each, must be handled by 2 people at a time. The other components, as they weigh less than 25 kg, can be transported and handled manually by a single person. For more details see Section 12.

## 6.3-Assembly of the platform

**IMPORTANT!**

**Risk of wounds and injuries due to fall of objects, fall from different level and / or breaks.**

Danger of death due to fall of objects, fall from different level and / or breaks.

-Before the assembly of the wire ropes ensure that the supporting point have enough capacity to support the efforts of the suspended loads.


List of materials and necessary tools for the assemble:

- Torque and ratchet wrenches for M12 and M16 hexagonal screws. 2 people.
- The following table shows the necessary fasteners and the correct torque setting:




	DESCRIPTION	INDICATIVE TORQUE SETTING	UNITS.
<b>T1</b>	ACCESUS fastener	-	-
<b>T2</b>	DIN931 M12x40 8.8 Screw + DIN985 Nut	62 Nm	4

The assembly of the modules can be done with any of the following two types of fasteners:

- ACCESUS Nut fastener with safety DIN985 nut and DIN125 washer.




- ACCESUS fastener with safety clip.




### 6.3.1-Assembly of the platform with carrier end panels.

The assembly of the scaffolding with the location of the fastener is described below:




Then place the floors and secure them with the 4 stops per floor.



## 6.3.1.1-Elevator assembly on the end panel.

Fix the elevator with 2 type T2 screws on the end panel





**DANGER!**

**Risk of wounds injuries or death  
due to fall of objects, fall from dif-  
ferent level.**


Danger of death due to fall from different level.

-It is very important to mount the elevators in the correct direction  
for the correct functioning of the safety devices securichute 600.

The other elevator will be fixed on the other end panel with the same 2 screws T2, but turning it on its vertical axis 180 degrees. In this way, the elevators will be mostly outside the platform, as shown in the following image.





The platform with carrier end panels is fully assembled.



### 6.3.2-Assembly of the platform with carrier pass-through stirrup.

The assembly is done in the same way as the platform with carrier end panels. The difference is that the platform is mounted on the pass-through stirrup. See the image on page 23 and table on section 6.2 for cantilever (L2 max).





List of materials and necessary tools for the assemble:

Torque and ratchet wrenches for M12 and M16 hexagonal screws. 2 people.

The following table shows the necessary fasteners (for 2 stirrups) and the correct torque setting:


	DESCRIPTION	INDICATIVE TORQUE SETTING	UNITS
<b>T2</b>	DIN931 M12x40 8.8 Screw+DIN985 Nut	62 Nm	4
<b>T3</b>	DIN931 M12x90 8.8 Screw+DIN985 Nut+2 DIN125 Washers	62 Nm	44
<b>T4</b>	DIN931 M12x190 8.8 Screw+DIN985 Nut+2 DIN125 Washers	62 Nm	4



Correct position of the anchor of the motor, centered on the tube

### 6.3.2.1-Assembly configurations of the pass-through stirrup.


The pass-through stirrup can be assembled in different configurations to place the motorized elevator at the desired height or the manual elevator, which has its specific height.




It is recommended to proceed with the assembly of the lowest possible configuration (in case of several options as is the case of the Leva), this will facilitate assembly of equipment, to later reconfigure the stirrup to the desired height with the help of the elevators.

### 6.3.2.2-Pass-through stirrup position in the platform.

The pass-through stirrups must be assembly respecting the maximum allowed cantilever of 3m. The distance L1 between stirrups is calculated in accordance with the cantilever data. See also table section 6.2.




The Komplet platform can be assembled using a step clamp and an extreme clamp. In this configuration, the restrictions in table 6.2 must continue to be respected.



### 6.3.2.3-Elevator assembly on the pass-through stirrup

The two elevators will be fixed (with 2 T2 screws each) in the same way that they were fixed on the platform with end panels, each rotated 180 degrees with respect to the other elevator of the other end panel. They will be placed so that the most protruding part of the engine with respect to the anchors will look towards end of the platform. See next image.




**DANGER!**

**Risk of wounds injuries or death  
due to fall of objects, fall from dif-  
ferent level.**


Danger of death due to fall from different level.

-It is very important to mount the elevators in the correct direction  
for the correct functioning of the safety devices securichute 600.





Check the correct mounting of the suspended scaffolding, especially that there is no un-mounted screws.

The platform with carrier pass-through stirrups is fully assembled.



### 6.3.3-Assembly and assembly of cabin with passing lyre



The assembly is carried out in the same way as the platform with carrier end liras. The difference is that this one is mounted on top of the passing lyres. See image p. 23 and table Section 6.2 For flight (L2 max).



Necessary materials:


Fixed and ratchet wrenches for M12 hex screw and 2 people. The following table indicates the necessary screws (for two lyre) and the correct tightening torque:

	DESCRIPTION	INDICATIVE TIGHTENING TORQUE	UTS.
<b>T2</b>	DIN931 M12x40 8.8 Screw+DIN985 Nut	62 Nm	2
<b>T3</b>	DIN931 M12x90 8.8 Screw+DIN985 Nut+2 DIN125 Washers	62 Nm	22
<b>T4</b>	Tornillo DIN 931 M12x190 8.8 + Tuerca DIN 985 + 2 Arandelas DIN125	62 Nm	2



Correct position of the anchoring of the motor, centered on the tube


### 6.3.2.1-Mounting configuration of the passing lyre.



### 6.3.2.2-Position of the passing lyre on the platform.

The passing lines must be mounted respecting the maximum allowed flight, of 3 m. The distance L1 between lines is calculated from the flight data. See also table section 6.2.

See section 6.2 table




Max. over-  
hanging  
(L2) = 1 m

The Komplet equipment can be assembled using a step clamp and an end clamp. The restrictions in Table 6.2 must still be respected in this configuration.

### 6.3.2.3-Assembly of the elevator in passing lyre.

The two elevators will be fixed (with 2 T2 screws each) in the same way as they were fixed on the platform with end lira, each one rotated 180 degrees with respect to the other elevator of the other passing lira. They will be positioned so that the most protruding part of the engine with respect to the anchors will face towards its end of the platform. See the following image.




**DANGER!**

**Risk of injuries, injuries and death by falling at different levels.**


Danger of death by falling at different levels.

-It is very important to mount the lifts in the correct direction for the proper operation of the securichute 600 safety devices.




Verify the correct assembly of the hanging scaffold, especially that there is no unassembled screw.

The cabin with passing lyre is fully assembled.




### 6.3.3-Guide wheels assembly

The guide wheels will serve to support the platform to the facade, protecting the latter from shocks or scratches. In addition it also improves the stability of the platform during work. It is a very important accessory.



### 6.3.4-Support wheels assembly

The support wheels of the platform will be useful to move the platform once it is on the ground.



## 6.4-Electric components

In the case of the platform equipped with two electric elevators Leva and its corresponding electrical cabinet.

Ensure that the power supply connector is compatible with the electric cabinet.

- Three-phase 400 V 50 Hz
- Mono-phase 230 V 50 Hz

- The power supply must be protected, before the connector, with a 16A differential circuit breaker 30 mA.
- The cable's gauge between the floor and the platform must be compatible with the power of the devices and the cable's length. See table:

				Minimum cross-section in mm <sup>2</sup> (per wire) for 2 Leva			
	Voltage	Max. cable speed		20 m	50 m	100 m	200 m
Leva	400V	8m/min	One winch	1.5	1.5	1.5	1.5
			Two winch	1.5	1.5	1.5	2.5


- Fix the electric cabinet on the handrail.

• Connect the power supply cable from the electric cabinet to the power supply hose by means of a CEE 16A connector. The hose must be fixed to the platform with a pin. For superior heights to 100 m you have to verify the efforts admitted by the cable.

• Connect the Leva hoist to the electric cabinet and check the correct running of the device. Before a working day is obligatory to check the stop emergency.

• The device is protected with a system of phase control relay. If this device doesn't work try to reverse the phases with a screwdriver. See attached photo.

• Earth wire is done through the power supply line. The earthing function must be checked (check the protective cable and isolation). Optionally additional measures will be necessary.



• If necessary, a generator with a power equivalent to three times the rated power of the winch (nominal power of the generator [kVA] = number of winches x nominal capacity of the winches [kW] x 3) can be used. The generator must be grounded by the operator. The earthing function must be checked (check the isolation protection).

## 6.5-Introduction of the wire ropes in the platform




**DANGER!**

Hurts for wire ropes manipulation.	Danger of cuts and scratches.
Risk of wounds and injuries due to fall of objects, fall from different level and / or breaks.	<p data-bbox="531 349 1474 454">Danger of death due to fall of objects, fall from different level and / or breaks.</p> <ul data-bbox="531 477 1474 1229" style="list-style-type: none"> <li>-Before the assembly of the wire ropes ensure that the supporting point have enough capacity to support the efforts of the suspended loads, described in section 6.1 of this manual.</li> <li>-Use suitable PPE's: harness, protective gloves, safety boots, protective helmet, etc.</li> <li>-Only use wire ropes specified by the manufactures.</li> <li>-Ensure that the wire rope's diameter is the same as indicated at the m.lift400 or Leva and securichute600 labels.</li> <li>-Ensure that the wire rope's length is enough for the height.</li> <li>-Ensure that the wire rope's tip is in good condition.</li> <li>-Avoid the loop's formation at the wire ropes when manipulating.</li> <li>-Place the platform in dead weight under the suspension.</li> </ul>

**Safety wire rope**

**Work wire rope**



### 6.5.1-Introduction of the work wire rope



1- Insert the tip of the cable into the elevator until it stops.

2.1- In case of m.lift400 manual hoist::

- Push the wire rope by turning the master crank in the rise direction. The wire rope is pulled by the adhesion system.
- Slightly lift the load.

2.2-In case of Leva electric hoist:

- Turn the electric cabinet selector to select one or another elevator.
- Press "UP" button and continue pushing the wire rope until the hoist tows the wire rope for itself.
- Press "UP" button until the wire rope gets slightly tight.



-Roll carefully the rest of the wire rope on the reels, one for each wire rope.

### 6.5.2-Introduction of the safety wire rope

1- Before to seep the secondary wire rope into the pulleys you have to verify that is not rolled with the suspension wire rope.

2.1-In case of m.lift400 manual hoist:

- Activate the brake pads through the reset handle (the brake pads can not be activated if the elevator is not loaded).
- Introduce the safety wire rope.


2.2-In case of e.Leva electric hoist:



**IMPORTANT!**

<b>Excessive wear in overspeed detection mechanisms of Securichute600 device.</b>	Danger of death due to fall of objects, fall from different level and / or breaks.
	- Block the stop emergency button of the securichute600 pressing and turning it.


- Block the stop emergency button, pressing and turning it.
- Push down the reset handle.
- Introduce the wire rope's tip into the securichute600 and slightly tight it.
- Unblock the stop emergency button, returning it.



3- Attach a Grip'cable clamp and a counterweight on the safety wire rope, about 20cm from the ground


4-Carefully roll in the reels, 1 for each cable, the excess cable that is not used

5- To remove the wire rope, block the emergency button by pressing and turning it, keep the reset lever fully and slowly pull the cable upwards after having removed the counterweight.



#### 6.6.2.1-Installation of counterweights

Lift the platform 50 cm, install the the 20 kg counterweight on the safety wire rope with the help of the Grip'cable clamp.



## 6.6-Running test



**DANGER!**

**Danger of death due to fall of objects, fall from different level and / or breaks.**

Danger of death due to fall of objects, fall from different level and / or breaks.

-Do not stay under suspended loads.

-If necessary, block the danger zone.



When performing the following tests, the equipment must be loaded with the maximum load limit, in order to be able to check the operation of the safety devices.

### 6.6.1- Running test for manual elevator m.lift400

#### 6.6.1.1- Check the operation of the manual elevation and descent system

##### Service brake



- Turn the main crank and the peg tooth crank together in the lift direction until the wire rope is tensioned. Arm the reset lever.



- Lift the platform 1m approximately.
- Stop the movement..

The elevator must hold the load at all times that no action is exerted on the cranks and the ratchet handle.

- Disarm the peg tooth crank. Turn the main crank in the downward direction while holding the ratchet handle forward.




- Stop the movement without touching the ground.

The elevator must hold the load at all times that no action is exerted on the cranks and the ratchet handle.

### Ratchet brake


- Turn the main crank and the peg tooth crank together in lift direction until the work wire rope is tensioned. Arm the reset lever. Lift the platform 1m approximately .




- Stop de movement.

- Disarm the peg tooth crank. Turn the main crank in downward direction without activating the ratchet handle.

The platform will descend a few cm until the ratchet stops it. At that time the elevator must lock and hold the load.



- To descend, raise slightly again and then descend normally by means of the main crank in the downward direction while holding the ratchet handle forward.




### 6.6.1.2- Check the fall arrest device operation.


#### Load override

- Leave the platform on the ground, the fall arrest device is triggered by lack of load.
- To make sure that the fall arrest device has been triggered, lift the platform 1m again, without rearming the reset lever that had been triggered previously.

Handle in descent normally (disarm the peg tooth crank and turn the main crank in the downward direction while holding the ratchet handle in forward direction) until the wire rope locks.





- To rearm, lift the platform again 10 cm (until the work wire rope is tensioned).
- Actuate in forward direction the reset lever.





Great inclination of the platform



- Turn the main crank and the peg tooth crank together in the lift direction until the wire rope is tensioned. Arm the reset lever forward.



- Lift the platform horizontally approximately 1m.
- Stop the movement.
- Maneuver one of the elevators in downward direction
- Between 10° to 20° of inclination, the fall arrest device is triggered.



- To arm, raise again the lower elevator until the work wire rope is tensioned and assemble the reset lever forward.
- Press the reset lever forward.



**End of the check:** Record the result of the checks in the log book..

## 6.6.2- Running test for electric elevator Leva

### 6.6.2.1- Check the operation of the electric elevation system

#### Check the service brake

- Connect the lift upwards until the wire rope is tightened.
- Raise the load approximately 1m
- Stop the movement.
- Move it down.
- Stop the movement.

The stopping distance must not exceed 10cm. The elevator must hold the load.

- Download the load and loosen the wire rope.
- Stop the elevator.

The elevator must hold the wire rope.

If the lift does not hold the load, the wire rope and / or the stopping distance is greater than 10cm, have the elevator checked and repaired by ACCESUS or an authorized workshop by ACCESUS.

#### Check the operation of the detectors

**A-** Check the UPPER limit switch, see section 7.6.

- Shoot the limit switch manually.
- The upward movement must be stopped, the winch must hold the load and the descent must be possible.

**B-**Check the last limit switch (see section 7.6).

- Manually trip the switch. The electrical supply to the motor must be disconnected immediately.
- The winch must hold the cable. Upward movement should not be possible or falling.

**C-** Check the phase control relay, see section 7.7

If the phase control relay does not disconnect the drive when it is first connected and the drive is moved in the correct direction with the UP button, everything is correct. If the direction is not correct or the phase control relay disconnects the drive, use the phase inverter, see 7.7.

#### Check operation emergency stop

- Connect the lift upwards until the wire rope is tightened.
- Press EMERGENCY STOP

The power supply to the motor must be switched off immediately. The elevator must hold the wire rope.

#### Check emergency lowering operation

- Raise the load approximately 0.5m.
- Stop the movement.
- Carry out an emergency descent maneuver.

The emergency lowering speed must be constant around 4.5m / min.

- Stop movement.

The stopping distance must not exceed 10cm. The elevator must hold the load.

6.6.2.2- Check the operation of the securichute600 fall arrester (see section 11.4)

Verify that the securichute600 ensures the attachment to the cable.

- Press the emergency button of the securichute600. The jaws must close automatically and it must be impossible to pull the wire rope upwards manually.

- Rearm the securichute600 by actuating the reset lever. The safety wire rope must be able to move freely through the securichute.

**End of the check:** Record the result of the checks in the log book..

## 7-Safety devices

In order to guarantee a correct working order of the TSP and safety for the workers, the platform with manual hoists m.lift400 has the follow safety devices:

### 7.1-Integrated safety devices in manual hoist m.lift400

a) The main brake system guarantees a complete and automatic security as soon as the crank has been let go.

b) A mechanical overload detector ensures complete safety if there is an overload on the platform or that this trip over a ledge during ascent.

c) In case of cancellation of the load (insufficient load, tearing of the working wire-rope) a rope gripping instantly grips onto the safety rope which then bears the full load.

d) In case the platform starts tilting, an anti-slant system blocks the sliding. This may occur during the lowering of the platform, if the two winches are not operated at the same speed. In this case, put the platform horizontal again by using only the winch that caused the slant. To unblock the anti-slant device, lift the platform and push the reset lever.

e) A ratchet in direct drive in the grip wheel assures the security in the case of a defect in the brakes.

f) In case one of the working ropes should slide (faulty grip system), the anti-slant system blocks further lowering.

In order to guarantee a correct working order of the TSP and safety for the workers, the platform with Leva hoists has the follow safety devices:

### 7.2-Integrated safety devices in electric hoist Leva

a) A brake system works in case of absence of electric supply or when the worker does not press the UP or DOWN buttons.

b) The electromechanical overload sensor stops the electric supply in case of overload at the platform or in case of setback during the ascend.  
The overload is indicated through the illuminated pushbutton located at the electric hoist., optionally by the acoustic alarm (H1) of the electrical cabinet.


c) The upper limit switch sensor stops the ascent when the bolt touches the upper limit.

### 7.3-Integrated safety devices in electric cabinet

In case of emergency the platform's movement can be stopped immediately pressing the "STOP EMERGENCY" button (S0) located at the electric cabinet.

When the emergency has disappeared spin the button in arrows direction, press the GREEN start button (S1). Finally use the UP (S3) or DOWN (S4) buttons.

Inclination sensor stops the movement in case of excessive inclination.



## 7.4-Fall arrest device system securichute600

When the platform is running the secondary wire rope pass freely into the gags.


If the safety wire rope is blocked it might be due to the following reasons:

- a) break of the work wire rope,
- b) elevator breakdown,
- c) any problem with the hoist that causes an increase of the velocity,
- d) a crash,
- e) overtilting of the platform,
- f) STOP EMERGENCY button is blocked,
- g) gags not reset.

For a) and b) cases it's necessary to do a particular emergency operation.

For c), d), e), f) and g) cases the worker must tense the suspension wire rope using the Leva hoist. After that go up some centimeters, unblock the STOP EMERGENCY button and push the RESET handle of the securichute600 fall arrest device until his open position.

If the powered hoist glides, the worker can stop the platform pushing the STOP EMERGENCY button of the securichute600 fall arrest device.



**Leva  
+ Securichute600**

## 7.5-Overload safety system in Leva

The overload safety device integrated at the hoist stops completely the platform in this cases:

- a) Overload or incorrect load distribution at the platform,
- b) The platform has an obstacle during the ascent.

An acoustic bleeper, placed at the electric cabinet, reports this overload.

If the platform has overload it's necessary to remove the load over the platform or the obstacle.



### NOTE

If it is necessary to adjust the overload limit, request the procedure from ACCESUS by one of the means indicated in section 1


## 7.6-Upper and final limit switch in Leva

The ascent of the platform stops when the upper limit switch touches the end fixed disk at the wire ropes.

The descent continues being possible.

In case of error, this device has a second contact that stops all the platform's movements.


The upper limit switch must be installed on safety wire ropes, 20-30cm under height of the wire hook.



## 7.7-Phase controller

The three-phase equipments has a device which controls the direction of the phases. It is placed at the electric cabinet. This phase controller stops the power supply in case of an erroneous connection.

It's possible to invert the phases at the CEE connector by rotating 180° with a screwdriver.




## 7.8-Emergency descent in Leva

The powered hoists are equipped with a manual system that allows the descent of the platforms in case of no power supply.

The lever of emergency descent allows to descend with a controlled velocity in every moment.

EMERGENCY  
DESCENT lever





**Leva  
+ Securichute600**

## 7.9-Acoustic bleeper (Optional).

The acoustic bleeper (H1) of the electric cabinet it can be use for a S.O.S. message or for advert to other workers. This sign runs when the EMERGENCY STOP button is blocked and acting simultaneously on the UP (S3) or DOWN (S4) selector.

## 7.10-EN795 anchor point (optional)

The Komplet platform can have 1 EN 795 anchorage point for up to 2 persons at each end of the platform (A).



Anchor point (A)  
PAF180-12


**¡DANGER!**

**Danger of death due to fall of objects, fall from different level and / or breaks.**

Danger to life due to falling objects, falling from a different level and/or breakage

-ONLY EN 354 lanyard with EN 355 absorber may be used. Maximum length 2m.

-It is strictly forbidden to install a horizontal lifeline between the two anchor points.



These anchor points are useful for platforms up to 4m long, using 2m long lanyards. For longer platforms see option 1 in section 8.1 of this manual.

## 8-Operating the platform

### 8.1-Preliminary checks

- a) Use only wire ropes specified by ACCESUS. It must be replaced if there are any damages such as described at section 11.2.1.
- b) Verify the correct working order of hoist, brake engine, securichute, limit switch, overload, stop emergency, acoustic bleeper, etc.
- c) Verify the safety of the suspensions and ensure that all the components and counterweights are there. Control specially the hooks and the wire rope's fixation.
- d) Ensure that the suspensions are in dead weight with the platform.
- e) Ensure that the load over the platform not exceeds the weight load limit including snow, ice, materials...
- f) **To cover risks arising from misuse, the use of personal protective equipment (PPE) is mandatory for operators:**



### **DANGER!**

<b>Danger of death due to fall of objects, fall from different level and / or breaks.</b>	Danger of death due to fall of objects, fall from different level and/or breaks.
	- Can be anchored <b>ONLY</b> by one of the following two systems, <b>NEVER</b> both at the same time.

#### **OPTION 1:**

Use of EN361 harnesses and fall arresters EN353-2 with the corresponding lifeline with a length equal to or greater than the cables.

The lifeline, to which the operator will join by means of the fall arrester, must always be anchored to a resistant element independent of the platform and the suspension.


#### **OPTION 2:**

Use of harnesses EN361 and anchoring sling (EN354) with absorber (EN355) anchored to one of the anchor points (EN795) provided by the platform (see section 7.10)

In addition all operators must be equipped with all necessary PPE:

- harness,
- 2 metres EN 354 lanyard with absorber EN 355,
- safety gloves,
- security boots,
- helmet with barbell,
- suitable work clothes.

**Anchor points**



g) It is recommended to sign correctly the floor's area susceptible of objects fall (tools, materials...) used at the platform and under the guide rope as well. This recommendation becomes mandatory when the public can access the area.

h) The equipment is intended to be used in luminous areas (natural or artificial). In case of use artificial illumination, the worker must dispose with enough light.

i) Ensure that the temperature of the environment is over  $-10^{\circ}\text{C}$  and under  $+55^{\circ}\text{C}$ .

j) Don't work in case of hard wind (superior to 50 km/h) or storm.

k) When the work is finished, the responsible of the work must place the platform out of service and switch off the power supply.

**It is forbidden to:**

- a) Use the platform with no safety wire rope and no securichute600 fall arrest device.
- b) Deactivate the safety devices (overload, upper limit switch...)
- c) Overload the platform.
- d) Loads over the people.
- e) Descend the platform manually with the brake of the Leva hoist when the powered descent is possible.

**In some countries of the European Union is obligatory an exam of the commissioning, before the works, by an authorized organism.**


## 8.2-Rated capacity




### IMPORTANT!


The loads will be calculated as follow:







– The first and second person is calculated with a weight of 80 kg + 40 kg for tools and materials. The following people are calculated with 80 kg.


The load must be distributed uniformly all over the platform.










With 1 elevator		Platform with carrier end panels			
Elevator	Platform length (m)	0,5	1	1,5	2
Leva	 Weight load capacity (kg)	120	240	240	120
	 Number of people	1	2	2	1
	 Dead weight (kg)	170	180	190	200

**LOAD CAPACITY**


With 2 elevators		Platform with carrier end panels													
Elevator	Platform length (m)	2	3	4	5	6	7	8	9	10	11	12	13	14	15
m.lift® 400	 Weight load capacity (kg)	250	380	510	560	450	390	360	-	-	-	-	-	-	-
	 Number of people	2	3	4	5	4	3	3	-	-	-	-	-	-	-
	 Dead weight (kg)	165	185	215	235	250	275	295	-	-	-	-	-	-	-
Leva	 Weight load capacity (kg)	380	570	650	630	610	580	560	530	510	410	330	260	210	170
	 Number of people	2	3	4	5	6	6	6	5	5	4	3	2	1	1
	 Dead weight (kg)	240	260	290	310	325	350	370	385	415	435	450	480	505	530

**LOAD CAPACITY**


With 2 elevators		Platform with carrier pass-through stirrup																		
Elevator	Total platform length L (m)	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
	Maximum distance between stirrup L1(m)	2	3	4	5	6	7	8	9	10	11	12	12	12	12	12	13	14	15	16
	Cantilever max L2(m)	0,5	0,5	1	1	1,5	1,5	2	2	2	2	3	3	3	3	3	3	3	3	3
m.lift® 400	 L2 Cantilever Weight load capacity L2 (kg)	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120	120
	 L Weight load capacity (cantilever included) L (kg)	380	450	450	450	390	360	-	-	-	-	-	-	-	-	-	-	-	-	-
	 Number of people	3	4	4	4	3	3	-	-	-	-	-	-	-	-	-	-	-	-	-
	 Dead weight (kg)	285	315	335	350	375	395	-	-	-	-	-	-	-	-	-	-	-	-	-
Leva	 L Weight load capacity (cantilever included) L (kg)	570	620	590	570	540	520	500	470	450	410	400	370	340	320	300	280	240	190	150
	 Number of people	3	4	5	6	5	5	5	4	4	4	4	3	3	3	2	2	2	1	1
	 Dead weight (kg)	360	390	410	425	450	470	485	515	535	550	580	605	630	655	675	700	730	755	775

The **maximum** overrun (L2) authorized is 3m.

### 8.3-Guiding the platform along the facade

For platforms working at heights superior to 40m with a wind velocity of more than 50 km/h, the lateral movements must be controlled through an appropriate retention system.

A guiding system by anchor points distributed every 20m and a tie finished in a ring, which is passed around the wire ropes

The anchor points are placed in the **first descent**; therefore the first ascent takes place without anchoring.

### 8.4-Loading / unloading areas

Whenever possible, loading and / or unloading at the lower level.

To carry out the **loading and / or unloading on a different level than the lower one**, the following guidelines must be followed:

-The operator must have the approval of the safety responsible person of the work to carry out the unloading maneuver on a different level than the lower one.


-There must be a written document for a loading procedure at a different level than the lower one. The procedure should include eventual rescue.

-The operator must be equipped with suitable PPE's for the maneuver to be carried out: Harness, double anchor sling, helmet with barbell, and all the necessary PPE's.

-The operator must be at all times anchored to an anchorage point enough resistant and in accordance with the standard EN795, during the unloading maneuver and until it is located in a safe area protected by handrail.



-It is forbidden to carry out this maneuver alone.

### 8.5-Operating of the manual hoists m.lift400





### To raise

- Turn the crank handles, in the clockwise direction. Arm the reset lever forward as soon as the work wire rope is tensioned.






### to lower

- Loosen the left crank handle (handle pointing downwards)
- Hold the ratchet and turn the main crank handle in the downward (opposite direction to clockwise).



### In case of block in descending

- Raise the platform few cm until the work wire rope is loaded.
- Open the jaws by reset handle. It must be open.
- Open the ratchet by ratchet handle and turn the crank in the opposite direction to clockwise.




## 8.6-Electric controls

Up and down platform movements are controlled from the electric cabinet placed in the middle of the platform.

In case of an error, wait until that movement finish completely before effectuate other order. The buttons has an immediate action.

**Avoid maneuvers with consecutive impulses at the control.**



In case of emergency, the movement of the platform can be immediately stopped by pressing the “emergency stop” (S0) in the electrical cabinet.

Once the cause of the emergency has disappeared or eliminated, turn the button in the direction indicated by the arrows, press the GREEN start button (S1). Finally use the UP (S3) or DOWN (S4) selector.

The inclination detector stops movement in case of excessive inclination:

- A contact that cuts the feeding of the elevator in upper position. The operator keeps pressing UP: The elevator that had stopped automatically (the upper one), will continue its movement as soon as the platform returns to recover the horizontal position.

- Similarly in descent it cuts the feeding of the lowest elevator. The operator continuous pressing DOWN: The elevator that had stopped automatically, will continue its movement as soon as the platform returns to recover the horizontal position.


## 8.7-No power emergency descent

**It's forbidden to descend the platform using the Leva hoist brake when the electric descent is possible**

The powered hoists are equipped with a manual descent system in case of no power supply:

- a) Stop the power supply by disconnecting the socket.
- b) Raise without forcing the emergency lowering lever located at the rear of the lift to open the service brake. The platform descends under its own weight and its speed is limited and controlled automatically.
- c) If the event that the platform did not descend, an initial impulse must be given turning clockwise the maneuver's flywheel (2) located on the motor shaft after having removed the cap (4).
- d) The platform stops as soon as the brake lever is released.
- e) Once the platform is on the ground, remove the steering wheel and put it back in the support (3). Place the plastic cap (4) on top of the motor.

**In the event of an overload, a manual emergency lowering is prohibited.**



## 8.8-Action in case of the fall arrest locking


In case of securichute600 fall arrest block, act as follows

### If there are power supply.

Press "UP" at the electric cabinet until the work wire rope get tensioned. Open the reset lever on the securichute600 fall arrest device. Now you can continue working.

### If there aren't power supply.

Remove the plastic cap (2) from its support (3). Remove the plug (4) and insert the flywheel (2) on the motor shaft until it snaps into it. Turn the steering wheel located on the motor shaft in a clockwise direction while opening the motor brake by lifting the lever (1) without forcing, until the work cable is under tension. Open the securichute600 reset lever. You can now continue working normally.



Leva  
+ Securichute600

## 8.9-Request for help with the acoustic bleeper (optional)

In case of emergency or request for help.

The ACOUSTIC (H1) bleeper placed in the electric cabinet can be used as an S.O.S. distress signal or to advert other workers. This sign is activated with the EMERGENCY STOP button (SO) blocked and pushing START (S1) button.

**S.O.S. is the most used distress signal. Consists of a continuous sequence of three-dots / three-dashes / three-dots, all run together without letter spacing.**

## 8.10-Moving the platform horizontally

For the displacement of the platform two operators are needed, one at the level of suspension structure and another on the platform. When working at the level of the suspension they must be equipped with a harness that is anchored to a anchor point with sufficiently capacity load.

1-Place the platform about 30cm above ground level.

2-Remove the counterweights from the safety wire ropes.

3-Leave the safety wire ropes loose enough.

4-Support the platform on the ground and leave the work wire ropes loose. **Never remove the wire ropes from the suspension structure.**

5-Move the suspensions to the new position (release the brakes on its wheels and lock them again once the suspension have been placed in their new location).


6-Move the platform until is in the vertical of the suspensions.

**7-Avoid placing the platform by means of elevators;** It could cause a dangerous swaying or a deterioration of the material.

8-Tension the work wire ropes by pressing the UP button.

9-Lift the platform about 30cm.

10-Tension the safety wire ropes by hand and hook the counterweights to each safety wire rope. Carefully wind the unused length of wire rope in the winders.



## 8.11-Removing the wire ropes

**DANGER!**

Hurts for wire ropes manipulation.	Danger of cuts and scratches.
Risk of wounds and injuries due to fall of objects, fall from different level and / or breaks.	Danger of death due to fall of objects, fall from different level and / or breaks.
	<p>-Before to remove the wire ropes and during the maneuver, ensure that nobody is on the danger's area.</p> <p>-Use adequate PPE's: harness, protection gloves, safety boots, helmet, etc.</p> <p>-Avoid the creation of loops when manipulating the wire ropes.</p> <p>-It must be communication in order to coordinate the maneuvers between the workers at ground and the workers at the roof beam.</p>

For removing the wire ropes are necessary 2 people, 1 at the at the suspension area or roof beam and 1 at the base of the support zone of the platform.

a) Get down the platform until the ground and loose the wire ropes.

b) Extract the suspension wire rope from the hoist pressing the "descend" button, or manually.

c) Extract the safety wire rope from the fall arrest device.

d) Move the roof beams or suspension towards inside the roof of the building.

e) At the ground start to wind up correctly the first section of the work and safety wire ropes cables on their winders

f) The operator located on the roof, will disengage one per one the wire ropes from the suspensions and with a rope of appropriate length will leaving them down to the ground. **Do not drop the wire ropes in free fall.**

g) The operator on the platform level will correctly wind up the work and safety wire ropes into their winders.

## 8.12-Dismantling the platform

**DANGER!**

Hurts for wire ropes manipulation.	Danger of cuts and scratches.
Risk of wounds and injuries	Danger of death due to fall of objects, fall from different level and / or breaks.
due to fall of objects, fall from different level and / or breaks.	<p>-Before to remove the wire ropes and during the maneuver, ensure that nobody is on the danger's area.</p> <p>-Use adequate PPE's: harness, protection gloves, safety boots, helmet, etc.</p> <p>-Avoid the creation of loops when manipulating the wire ropes.</p> <p>-It must be communication in order to coordinate the maneuvers between the workers at ground and the workers at the roof beam</p> <p>-Use intercoms for the coordination of maneuvers between operators.</p>

To dismount the platform follow inversely the steps described at section 6.3.

## 9-Residual risks not covered by the design of the TSP

- The platform is not equipped with an anti-collision device which stops automatically the ascent or descent in case of obstacle.

The worker must verify visually if there are any obstacles in the trajectory.



**DANGER!**

- SECURICHUTE600 fall arrest device is not equipped with a device which stops automatically the ascent or descent in case of block.

The worker must verify visually if the SECURICHUTE600 gets blocked and realize the maneuvers described to unblock.

If the SECURICHUTE600 is blocked, the platform can ascend normally but can not descend cause it will be suspended by the safety wire rope. If this case is given see the section 8.8 described in this manual.

- The noise level generated by the Leva powered hoist has a maximum of 70dB (A) from a distance of 1m.

- Don't work with wind superior to 50 km/h (14 m/sec).

- It's forbidden to work in case of strong wind or storm.

## 10-Troubleshooting



### DANGER!

**Risk of wounds injuries or death due to fall of objects, fall from different level, breaks and/or electric-contact.**

Danger of death due to fall of objects, fall from different level and / or breaks. Danger of death by electric contact..

- Stop the works immediately..
- Identify the cause and solution the breakdown.
- Before the works disconnect the power supply plug (CEE) of the platform. The worker must verify in every moment that the plug is disconnected.

These are the instructions to identify and repair the breakdowns **for platforms equipped with m.lift400 hoist.**

Breakdown	Probable reason	Solution
m.lift400 hoist doesn't ascent.	-Grip system worn out. -Grooved pulley worn out or dirty.	-The device must be checked by ACCESUS.
m.lift400 hoist doesn't descent.	-Rope gripping security activated. -Ratchet caught.	-See section 8.5 of this manual.
Slow sliding	-Grip system worn out. -Grooved pulley worn out or dirty. -Brake worn out.	-The device must be checked by ACCESUS.
Safety wire rope is blocked	-Rope gripping security activated. -Grooved pulley worn out or dirty. -Brake worn out.	-See section 8.5 of this manual. -If the problem continues, the device must be checked by ACCESUS.

These are the instructions to identify and repair the breakdowns **for platforms equipped with m.lift501 hoist.**

Break-down	Probable reason	Solution
The motor does not rotate	<ul style="list-style-type: none"> <li>-The brake without power is disconnected or out of order.</li> <li>-The temperature sensor is activated.</li> <li>-The overload is activated.</li> <li>-The motor has a mechanical fault.</li> <li>-The contactor in the hoist is out of order or disconnected.</li> <li>-The general contactor of the control box is out of order or disconnected.</li> <li>-The limit switch is activated.</li> <li>-Fault in the control circuit.</li> <li>-Fault in the power circuit.</li> <li>-Power supply fault.</li> <li>-Humidity "jams" the brake on the motor.</li> </ul>	<ul style="list-style-type: none"> <li>-Reconnect the brake or change it.</li> <li>-Wait for a drop in temperature.</li> <li>-Reduce the load.</li> <li>-Check the motor.</li> <li>-Reconnect or replace it.</li> <li>-Reconnect or replace it.</li> <li>-Have a competent person check it.</li> <li>-Check.</li> <li>-Have a competent person check it.</li> <li>- "Tap" gently on the motor spindle while-pressing on the control buttons.</li> </ul>
The hoist- does not rise	<ul style="list-style-type: none"> <li>-The grooved pulley is worn or dirty.</li> <li>-The starting condenser and the centrifugal coupler are disconnected or out of order (only for a single phase hoist)</li> <li>-The temperature sensor is activated.</li> <li>-The overload is activated.</li> <li>-The motor is blocked.</li> <li>-The contactor on the hoist is out of order or disconnected.</li> <li>-The limit switch is activated.</li> <li>-Fault in the control circuit.</li> <li>-Fault in the power circuit.</li> </ul>	<ul style="list-style-type: none"> <li>-Verification.</li> <li>-Verification.</li> <li>-Wait for a drop in temperature.</li> <li>-Reduce the load.</li> <li>-Check.</li> <li>-Verification (maintenance).</li> <li>-Reconnect or replace it.</li> <li>-Have a competent person check it.</li> </ul>
The hoist does not descend	<ul style="list-style-type: none"> <li>-The fall-prevention system is engaged</li> <li>-The temperature sensor is activated</li> <li>-The overload is activated</li> <li>-The lack of load is activated (optional)</li> <li>-The motor is blocked</li> <li>-The contactor in the hoist is out of order or disconnected</li> <li>-Fault in the control circuit</li> <li>-Fault in the power circuit</li> </ul>	<ul style="list-style-type: none"> <li>-Verification</li> <li>-Wait for a drop in temperature</li> <li>-Reduce the load</li> <li>-Check then press the red button of each hoist.</li> <li>-Check the motor</li> <li>-Reconnect or replace it</li> <li>-Have a competent person check it</li> </ul>

The motor is powered but stalls chugging)	<ul style="list-style-type: none"> <li>-The brake without power is disconnected or out of order.</li> <li>-The starting condenser and the centrifugal coupler are disconnected or out of order (only for a single phase hoist).</li> <li>-The motor is blocked.</li> <li>-Fault or one phase missing in the power circuit</li> <li>-Supply lead section too small</li> </ul>	<ul style="list-style-type: none"> <li>-Reconnect the brake or change it</li> <li>-Verification</li> <li>-Verification (maintenance)</li> <li>-Check the power supply</li> <li>-Replace the power cable</li> </ul>
The hoist does not lift the load	<ul style="list-style-type: none"> <li>-The grooved pulley is worn or dirty.</li> <li>-The permanent condenser is out of order.</li> <li>-The starting condenser and the centrifugal coupler are disconnected or out of order (only for a single phase hoist)</li> <li>-The temperature sensor is activated</li> <li>-The overload is activated.</li> <li>-Fault or one phase missing in the power circuit.</li> <li>-Supply lead section too small.</li> </ul>	<ul style="list-style-type: none"> <li>-Verification</li> <li>-Verification</li> <li>-Verification</li> <li>-Wait for a drop in temperature</li> <li>-Reduce the load</li> <li>-Check the power supply</li> <li>-Replace the supply lead</li> </ul>
Current too high	<ul style="list-style-type: none"> <li>-The brake without power is disconnected or out of order.</li> <li>-The permanent condenser is disconnected or out of order.</li> <li>-The motor is blocked.</li> </ul>	<ul style="list-style-type: none"> <li>-Reconnect the brake or change it.</li> <li>-Reconnect the condenser or change it.</li> <li>-Verifications (maintenance).</li> </ul>
Slow sliding	<ul style="list-style-type: none"> <li>-The grooved pulley is worn or dirty.</li> <li>-The brake without power is worn.</li> <li>-The adherence system is worn or dirty.</li> </ul>	<ul style="list-style-type: none"> <li>-Verification.</li> <li>-Replace the brake.</li> <li>-Verification.</li> </ul>
Uncontrolled manual descent	<ul style="list-style-type: none"> <li>-The manual lowering condenser is worn.</li> </ul>	<ul style="list-style-type: none"> <li>-Replace the condenser.</li> <li>-Check the contactor in K1 and K2.</li> </ul>
Manual descent not possible	<ul style="list-style-type: none"> <li>-The brake without power is jammed.</li> <li>-The fall-prevention system is jammed.</li> <li>-The load below the hoist is too little to initiate the movement</li> </ul>	<ul style="list-style-type: none"> <li>-Verification.</li> <li>-Use the hand wheel.</li> </ul>

## 11-Maintenance



**¡PELIGRO!**

<b>Risk of wounds injuries or death due to fall of objects, fall from different level, breaks and/or electric contact.</b>	Danger of death due to fall of objects, fall from different level and / or breaks. Danger of death by electric contact.
	-Stop the works immediately. -Identify the cause and solution the breakdown. -Before the works disconnect the power supply plug (CEE) of the platform. The worker must verify in every moment that the plug is disconnected.

Take into account the maintenance work and intervals described below:


Interval	Work	Execution
Daily	-Check lift attachment. -Check the SECURICHUTE600 fall arrester, see section 11.4. -Check for dirt on the wire rope. -Proof of operation, see section 6.6	User
Weekly	-Check wire rope, see section 11.2.1. -Check connection hose and control hose	User
1 time per year	-Check of complete security of the equipment	ACCESUS or a workshop authorized by ACCESUS
when necessary	-Clean, lubricate and / or replace the wire rope, see section 11.2 and 8.9. -Clean the lift, see section 11.1 and 11.3. -Clean the limit switches, lubricate the limit switch drive. -Lubricate the traction device.	A person named and formed by the operator

## 11.1-Regular maintenance of the hoist m.lift400

Manual winches must be serviced each 6 months of operations.

Lubricating the brake system

- Remove the main crank
- Unscrew the 3 access screws
- Remove the brake unit.
- Grease the brake system



## 11.2-Wire ropes

Only the wire ropes recommended and supplied by ACCESUS guarantee the operation of the lifts

Cleaning: If necessary, brush dry, dirty wire ropes and, if necessary, grease them again.

**NEVER CLEAN WIRE ROPES WITH HIGH PRESSURE WATER!**

Greased: Lifting wire ropes should be greased regularly. To do this use IGOL SHP 50 grease or equivalent and distribute it by means of a cloth along the length of the wire rope.

**NEVER LUBRICATE THE CABLE WITH LUBRICANTS CONTAINING BISULPHITES! (eg Molycote).**




### 11.2.1-Replacing the wire ropes

Only wire ropes recommended and supplied by ACCESUS guarantees the start up of the hoists safely

The wire rope has a nominal pipe size of 8,3mm, a hook with a safety clip in one end and a rounded tip at the other side. The wire rope has a nameplate which identifies the origin, diameter and length.

The wire rope must be replaced in this cases:

- Reduction of the diameter. Minimum diameter 7,4 mm (for a wire rope with a nominal pipe size of 8,3 mm).
- Breaking of more than 10 threads over a length of 25 cm for a wire rope of Ø8,3 mm.
- Deformity or breaking of his clamps.
- Wire rope crushed or stripped.
- Hard oxidation.



### 11.3-Elevator

No maintenance is required on the engine, gear or brake until it reaches the annual review interval.

- In case of dirt, clean from the outside.
- Keep brake free of oil and grease.

### 11.4-Fall arrest device securichute

Control regularly the correct start up of the fall arrest devices securichute600.

If the fall arrest device doesn't work correctly when performing the following tests, it must be replaced and repaired immediately by ACCESUS or by an authorized repairer.

#### 1- Diary verification:

Verify that the securichute600 holds correctly the secondary wire rope.

- Press the emergency stop button. The clamps must close automatically and be impossible to take out the wire rope manually.

- Reset the securichute600 pressing the reset handle. The safety wire rope must flow freely inside the fall arrest device securichute600

#### 2-Weekly verification weekly:


With the platform on the ground:

- Pull up, with a strong and quick blow, the safety wire rope. The securichute600 must subject immediately the wire rope. Repeat this operation at least 3 consecutive times.
- Reset the securichute600 by actuating his reset handle.

RESET lever  
**OPEN**


RESET lever  
**CLOSED**

EMERGENCY  
STOP button



## 12-Spare parts

### 12.1-ACCESUS KOMPLET platform



Pos.	Description	Weight (kg)	Handling
a	Floor panel 2m	11	1 person
b	Floor panel 3m	16	1 person
c	Connection stirrup	6	1 person
d	End panel	13	1 person
e	Side panel 2m	11	1 person
f	Side panel 3m	17	1 person
g	Handrail 2m	2	1 person
h	Handrail 3m	3	1 person
i	Pass-through stirrup	50	2 persons
j	Support wheel	11	1 person
k	Guide wheel	2	1 person
l	Elevator	53	2 persons
T1	DIN931 M12x40 8.8 Screw + DIN985 Nut	-	-
T2	DIN931 M12x90 8.8 Screw + DIN985 Nut + 2 DIN125 Washers	-	-
T3	DIN931 M12x190 8.8 Screw + DIN985 Nut + 2 DIN125 Washers	-	-
T4	DIN931 M12x190 8.8 + Tuer. DIN985 + 2 Ar. DIN125	-	-

## **12.2-Electric hoist Leva**

Indicate model, serial number and description of the hoist.

## **12.3-Manual hoist m.lift400**

Indicate model, serial number and description of the hoist.

## **12.4-Electric cabinet**


Indicate model, serial number and description of the electric cabinet. The electric scheme is inside the electric cabinet.

## **12.5-Fall arrest device securichute600**

Indicate model, serial number and description of the fall arrest device.

## 12.6-Nameplates and labels

Check the location of the labels.



Warnings label (3)

### WARNINGS OF USE

- This platform is destined for a professional use only. Only people with an adequate training and suitable for works at heights are authorized.
- For safety, it's essential for the worker to know and apply the instructions described at the Instructions Manual delivered with the platform.
- Don't exceed the Weight Load Limit or the number of people indicated at the platform's nameplate.
- Stop the works and put the platform on the ground if wind's velocity exceeds 14m/sec if it's a non guided platform or 16m/sec if it's a guided platform. Don't work with storm weather.
- If it's raining verify the engine's brake of the e.lift in order to avoid glidings.
- Before each start up, the machine must be verified by a competent person.
- A maintenance operation must be realized annually by Accesus.






ref.: 020020-000



Platform nameplate (1)





ref.: 200036-E001


## ACCESUS KOMPLET

m.lift400 / e.lift501 / LEVA


2025



L (m)	m.lift400 WLL= 400 kg			e.lift501/LEVA WLL= 500kg		
	RL (kg)		 (kg)	RL (kg)		 (kg)
2	250	2	165	380	2	240
3	380	3	185	570	3	260
4	510	4	215	650	4	290
5	560	5	235	630	5	310
6	450	4	250	610	6	325
7	390	3	275	580	6	350
8	360	3	295	560	6	370
9	-	-	-	530	5	385
10	-	-	-	510	5	415
11	-	-	-	410	4	435
12	-	-	-	330	3	450
13	-	-	-	260	2	480
14	-	-	-	210	1	505
15	-	-	-	170	1	530






c/Energia 54  
08940 Cornellà de Llobregat, Barcelona-SPAIN  
Telf.: (+34) 93 475 17 73  
accessus@accessus.es    www.accessus.es



Platform nameplate (2)





ref.: 200036-E002


## ACCESUS KOMPLET

m.lift400 / e.lift501 / LEVA


2025



L (m)	L1 max (m)	L2 max (m)	m.lift400			e.lift501/LEVA			
			CMU WLL (kg)	 L (kg)	 (kg)	CMU WLL (kg)	 L (kg)	 (kg)	
3	2	0,5	120	380	3	285	570	3	360
4	3	0,5	120	450	4	315	620	4	390
5	4	1	120	450	4	335	590	5	410
6	5	1	120	450	4	350	570	6	425
7	6	1,5	120	390	3	375	540	5	450
8	7	1,5	120	360	3	395	520	5	470
9	8	2	120	-	-	-	500	5	485
10	9	2	120	-	-	-	470	4	515
11	10	2	120	-	-	-	450	4	535
12	11	2	120	-	-	-	410	4	550
13	12	3	120	-	-	-	400	4	580
14	12	3	120	-	-	-	370	3	605
15	12	3	120	-	-	-	340	3	630
16	12	3	120	-	-	-	320	3	655
17	12	3	120	-	-	-	300	2	675
18	13	3	120	-	-	-	280	2	700
19	14	3	120	-	-	-	240	2	730
20	15	3	120	-	-	-	190	1	755
21	16	3	120	-	-	-	150	1	775




## Platform nameplate (3)

ref.: 200036-E003



## ACCESUS KOMPLET




e.lift501 / LEVA




---




2025

e.lift501 / LEVA WLL = 500kg			
L (m)	 (kg)	 (kg)	 (kg)
0,5	120	1	170
1	240	2	180
1,5	240	2	190
2	120	1	200



# accessus

c/Energia 54  
 08940 Cornellà de Llobregat, Barcelona-SPAIN  
 Telf.: (+34) 93 475 17 73  
[accessus@accessus.es](mailto:accessus@accessus.es)    [www.accessus.es](http://www.accessus.es)

## 13-Disposal and environmental protection

The equipment is made from recyclable materials. If the equipment is later scrapped, it must be disposed off correctly. The national versions of the waste legislation Directive 75/442/CEE apply within the European Union.

In accordance with Directive 2002/96/CE, the manufacturer is obliged to take back and dispose of specific pneumatic and electronic components. The following symbol is used on the nameplate of such components to identify them:



# 14-Model for Declaration of Conformity

ES	Declaración de conformidad	SE	Försäkran om överensstämmelse
EN	Declaration of conformity	GR	ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ
FR	Déclaration de conformité	PL	Deklaracja zgodności
IT	Dichiarazione di conformità	RU	СЕРТИФИКАТ СООТВЕТСТВИЯ
DE	Konformitätserklärung	HU	Megfelelőségi nyilatkozat
NL	Conformiteitsverklaring	CZ	Prohlá ení o shodù
PT	Declaração de conformidade	BG	ДЕКЛАРАЦИЯ ЗА СЪОТВЕТСТВИЕ
DK	Overensstemmelseserklæring	RO	Declaratie de conformitate
FI	Vastaavuusvakuutus	SK	Vyhlasenie o zhode
NO	Samsvarserklæring	SI	Izjava o ustreznosti

ACCESUS GROUP, S.L.

C/Energía 54, 08940 Cornellà de Llobregat (Barcelona) – SPAIN

Telf.: (+34) 93 475 17 73 - Email: [accesus@accesus.es](mailto:accesus@accesus.es) - Web: [www.accesus.es](http://www.accesus.es)

CERTIFICA QUE: El equipo designado es conforme con las reglas técnicas de seguridad que le son aplicables en la fecha de comercialización de la UNIÓN EUROPEA por el fabricante. DISPOSICIONES APLICADAS: Ver abajo / CERTIFIES THAT: The equipment designated is compliant with the technical safety rules applicable on the initial date of marketing in the EUROPEAN UNION by the manufacturer. MEASURES APPLIED: See below / CERTIFIE QUE: L'équipement désigné est conforme aux règles techniques de sécurité qui lui sont applicables à la date de mise sur le marché de l'UNION EUROPÉENNE par le fabricant. DISPOSITIONS APPLIQUÉES: Voir ci-dessous / CERTIFICA CHE: L'equipaggiamento designato è conforme alle regole tecniche di sicurezza ad esso applicabili alla data di messa, dal costruttore, sul mercato dell'UNIONE EUROPEA. DISPOSIZIONI APPLICABILI: Vedi soprastante / ERKLÄRT DASS: Die gegenüber bezeichnete Ausrüstung den techni-schen Sicherheitsbestimmungen entspricht, die zum Zeitpunkt des Inver-kehrbringens in der EUROPAISCHEN UNION durch den Hersteller für die Ausrüstung gelten. ANGEWENDETE VORSCHRIFTEN: Siehe unten / VERKLAART DAT: De in hieronder beschreven uitrusting conform de technische veiligheids voorschriften is die van toepassing zijn op de datum van de marktintroductie in de EUROPESE UNIE door de fabrikant. TOEGEPASTE SCHIKKINGEN: Zie hieronder / CERTIFICA QUE: O equipamento designado satisfaz as regras técnicas de segurança aplicáveis na data da introdução no mercado da UNIÃO EUROPEIA pelo fabricante. DISPOSIÇÕES APLICADAS: Ver abaixo / ERKLÄRER AT: Udstyret betegnet på modstående side er i overens-stemmelse med de gældende tekniske sikkerhedsforskrifter på den dato, hvor fabrikanten har markedsført det i den EUROPEISKE UNION. GÆLDENDE BESTEMMELSER: Se nedenfor / VAKUUTTA, ETTÄ: laite, johon tässä asiakirjassa viitataan täyttää tekniset turvamääräykset sinä päivänä, jona valmistaja tuo tuotteen myyntiin Euroopan unionin markkinoille. SOVELLETTAVAT MÄÄRÄYKSET: Katso alta / SERTIFISERER AT: Det udstyret som omtales på motsatt side er i overensstemmelse med de tekniske sikkerhetsregler som gjelder på det tidspunktet som fabrikanten setter utstyret i drift på markedet i DEN EUROPEISKE UNION. GJELDENDE NORMER: Se under / INTYGAR ATT: utrustningen som avses på motstående sida överensstämmer med de tekniska säkerhetsregler som är tillämpliga när produkten släpps på Europeiska unionens marknad. GÄLLANDE BESTÄMMELSER: Se ovan / ΒΕΒΑΙΩΝΕΙ ΤΙ: ε π λ ο σ ς π ο υ α ν α φ ε ρ ε τ α ι δ ε π λ α ε ν α ι ο ς φ ω ν ς π ρ ο ς τ ο υ ς τε ν ι κ ο ς καν ν ε ς ασφα λ ε ς π ο υ υ π ο υ ν κ α τ τ η ν η ε ρ η ν α δ ι θ ε ο ς ς τ ο σ τ η ν α γ ρ η ς ΕΥΡΩΠΑΪΚΗΣ ΕΝΩΣΗΣ ο π τ τ ο κ α τ α σ κ ε υ α σ τ . Ι Σ Υ Υ Σ Ε Σ Ι Α Τ Α Ε Ι Σ: Β λ π ε π α ρ α κ τ ω / ZAŚWIADCZA, ŻE: Sprzet określony na odwrocie odpowiada technicznym regulom bezpieczeństwa stosującym się do niego w dniu wprowadzenia przez producenta na rynek UNII EUROPEJSKIEJ. STOSOWANE PRZEPISY: Patrz niżej / AČIKLAMA: Tanımlanan donanımları, üretici tarafından AVRUPA BİRLİĞİ'nde piyasaya sürüldüğü zaman ilgili teknik güvenlik talimatlarını uyduğunu açıklamaktadır. KULLANILAN TALİMATLAR: bkz. Aşağıda / TANÚSÍTJA, HOGY: a szemközt megnevezett felszerelés megfelel a gyártó által az EURÓPAI UNIÓBÉLİ forgalmazás megkezdésének időpontjában érvényben lévő vonatkozó műszaki biztonsági szabályoknak. ALKALMAZOTT RENDELKEZÉSEK: Lásd alább / POTVRUJE, ŽE: Niže uvedené zařízen je v souladu s technickými pravidly bezpečnosti platnými ke dni jeho uvedení výrobcem na trh EVROPSKÉ UNIE. PLATNÁ USTANOVENÍ: Vviz níže / УДОСВОТВЕРЯВА, ЧЕ: Описаното настреча съоръжение съответства на приложимите за него технически правила за безопасност към датата на пускането му на пазара на ЕВРОПЕЙСКИЯ СЪЮЗ от производителя. ПРИЛОЖИМИ РАЗПОРЕДБИ: Виж по-долу / CERTIFICĂ FAPTUL CĂ: Echipamentul menționat alături este conform normelor tehnice de securitate aplicabile la data lansării pe piață EUROPEENE de către producător. DISPOZIȚII APLICATE: A se vedea mai jos / POTVRDZUJE, ŽE: Nižšie uvedené zariadenie je v súlade s technickými pravidlami bezpečnosti platnými ku dňu jeho uvedenia výrobcem na trh EURÓPSKEJ UNIE. PLATNÉ USTANOVENIA: Pozrite nižšie / POTRUIJE, DA: je opisana oprema skladna s tehničnimi pravili na področju varnosti, ki veljajo zanjo z dnem, ko jo proizvajalec pošlje na tržišče EVROPSKEUNIE. VELJAVNA DOLOČILA: glej spodaj

EN ISO 12100:2010  
EN 1808:2015.

2006/42/EC  
2014/30/UE

DESIGNACIÓN / DESIGNATION / DÉSIGNATION / DESIGNAZIONE / BEZEICHNUNG / BESCHRIJVING / DESIGNAÇÃO / BETEGNELSE / NIMITYS / BENEVNELSE / BETECKNING / ONOMAZIA / NAZWA / TANIMLAMA / MEGNEVEZÉS / NÁZEV / НАИМЕНОВАНИЕ / DENUMIRE / NÁZOV / OPIS

Plataforma suspendida de nivel variable / suspended access equipment / plates-formes suspendues à niveau variable / attrezzature per l'accesso sospenso / hängende Zugangsrausrüstung / hangende toegangapparatuur / equipamento de acesso suspenso / suspenderet adgangsudstyr / estetty pääsy laitteet / suspendert tilgangsstyr / upphängd åtkomstutrustning / εξοπλισμός αναστολής πρόσβασης / podwieszany sprzęt dostępowy / оборудование для подвешного доступа / felfüggesztett hozzáférésű berendezések / závěsné přístupové zařízení / оборудоване за качен достъп / echipamente cu acces suspendat / závěsné přístupové zariadenie / oprema za viseći dostop

APLICACIÓN / APPLICATION / APPLICATION / APPLICAZIONE / ANWENDUNG / TOEPASSING / APLICAÇÃO / ANVENDELSE / KÄYTTÖ / BRUKSOMRÅDE / ANVÄNDNING / ΕΦΑΡΜΓΗ / ZASTOSOWANIE / KULLANIM / ALKALMAZÁSI TERÜLET / APLIKACE / ПРИЛОЖЕНИЕ / DOMENIU DE APLICARE / APLIKÁCIA / UPORABA

Transporte de personas / Transport of persons / Transport des personnes / Trasporto di persone / Personentransport / Personentransport / Transporte de pessoas / Persontransport / Henkilöiden kuljetus / Persontransport / Persontransport / Αναβάθριο ατόμων / Transport osób / Személyszállítás / Přeprava osob / Personel taşıma / транспортиране на хора / Transportul persoanelor / Preprava osôb / Transport oseb



TIPO / TYPE / TYPE / TIPO / TYP / TYPE / TIPO / TYPE / ΤΥΠΟΙ / TYPE / TYP / ΤΥΠΟΣ / TYP / TIP / ΤÍΠΟΣ / TYP / ТИП / TIP / TYP/ TIP	
<b>KOMPLET</b>	
Equipado con / Equipped with / Équipé / Dotata / Ausgestattet mit / Uitgerust met / Equipado com / Udstyret med / Varusteltu / Utstyrt med / Utrustad med / Εξοπλισμένος με / Wyposażony w / Оснащен / Ellátva / Vybaven / Екипиран с / Echipat cu / Vybavené s / Opremljen z	
LEVA Nº: XXXX / XXXX ATURA Nº: XXXX / XXXX	
Armario eléctrico, Control box, boîtier de commande, Armário eléctrico, Armadio elettrico Nº XXXXXXXXXXXX	
Responsable de la documentación / Responsible for the documentation / Responsable de la documentación / Responsabile della documentazione / Dokumentationsverantwortlicher: / Documentatieverantwoordelijke / Responsável pela documentação / Dokumentationsansvarlig / Asiakirjan sisällöstä vastaava henkilö: / Dokumentasjonsansvarlig / Dokumentationsansvarig / Υπεύθυνος τεκμηρίωσης / Odpowiedzialny za dokumentację / A dokumentációért felelős személy: / Osoba odpowiedzialna za dokumentaci / Dokumentasyon sorumlusu / Отговорник за документацията / Responsabil cu documentația / Osoba zodpovedná za dokumentáciu / Odgovorna oseba za dokumentacijo	
ACCESUS GROUP, S.L. C/Energía 54, 08940 Cornellà de Llobregat (Barcelona) – SPAIN Telf. : (+34) 93 475 17 73 – Email : accesus@accesus.es	
Nombre / Name / Nom / Nome / Name / Naam / Nome / Navn / Nimi / Navn / Namn / Όνομα / Nazwa / Имя / Név / Název / Име / Nume / Názov / Ime	XXXXXXXXXX
Cargo / Charge / Bureau / Posizione / Position / Positie / Posição / Position / Asema / Posisjon / Placera / Θέση / Pozycja / Позиция / Pozíció / Pozice / Позиция / Pozitie / Pozícia / Položaj	XXXXXXXXXX
Lugar y fecha: / Place and date: / Lieu et date / Luogo e data / Ort und Zeit / Plaats en datum / Lugar e data / Sted og dato / Paikka ja päivämäärä / Sted og dato / Plats och datum / Μέρος και ημερομηνία / Miejsce i data / Место и время / Hely és dátum / Místo a datum / Място и дата / Loc și dată / Miesto a dátum / Kraj in datum	XXXXXXXXXX
Firma / Signature / Signature / Firma / Unterschrift / Handtekening / Assinatura / Underskrift / Allekirjoitus / Signatur / Signatur / Υπογραφή / Podpis / Подпись / Aláírás / Podpis / Подпис / Semnătură / Podpis / Podpis	



## 15-Machine's historic

Indicate the Serial Number of the machine and his components.

Machine or component	Serial number
Accesus KOMPLET suspended platform	
Leva Powered hoist / m.lift400 manual hoist	/
Securichute600 fall arrest device	/
Electric cabinet	
Date of start up	

Date	Maintenance according to ecc.11	Condition <b>OK</b>	Condition <b>NOT OK</b>	Identification and signature

## 15.1-Daily inspection report

This inspection report is indicative, in no circumstances Accesus will be responsible for the content or annotations.

It is mandatory to read and assimilate the instructions in the user manual before proceeding with the platform use or maintenance.

Responsible of the Inspection		
Company		
Date		
Location		
Indicate the machine serial number and its he components.		
	Model	Serial number
Platform		
Elevator 1		
Elevator 2		
Fall arrest device 1		
Fall arrest device 2		
Electric cabinet		
Electric cabinet		
	Elevator / Fall arrest device 1	Elevator / Fall arrest device 2
Wire ropes (work)	(1) Length:	(3) Length:
Wire ropes (safety)	(2) Length:	(4) Length:

Ref.	Description	Compliance	NOT Compliance		Comments
			Repairable	NOT repairable	
1	Platform				
1.1	Clean up				
1.2	Welds				
1.3	Handrails				
1.4	Floor panels				
1.5	Limit switch sensor				
1.6	End fixed disk				
2	Elevator 1				
2.1	Clean up				
2.2	Noise				
2.3	Vibrations				
2.4	Plug				
3	Elevator 2				
3.1	Clean up				
3.2	Noise				
3.3	Vibrations				
3.4	Plug				

Ref.	Description	Compliance	NOT Compliance		Comments
			Repairable	NOT repairable	
4	Fall arrest device 1				
4.1	Clean up				
4.2	Emergency stop				
5	Fall arrest device 2				
5.1	Clean up				
5.2	Emergency stop				
6	Electric cabinet				
6.1	Emergency stop				
7	Wire rope 1				
7.1	Hook and locking				
7.2	Wear				
8	Wire rope 2				
8.1	Hook and locking				
8.2	Wear				
9	Wire rope 3				
9.1	Hook and locking				
9.2	Wear				
10	Wire rope 4				
10.1	Hook and locking				
10.2	Wear				
11	Electric hose				
11.1	Plugs and connections				

**In case of detecting one or more not compliance points, the platform must be immobilized and prevented from being used until the detected defects are solved.**

## 15.2-Periodic inspection report

This inspection report is indicative, in no circumstances Accesus will be responsible for the content or annotations.

It is mandatory to read and assimilate the instructions in the user manual before proceeding with the platform use or maintenance.

Responsible of the Inspection		
Company		
Date		
Location		
Indicate the machine serial number and its he components.		
	Model	Serial number
Platform		
Elevator 1		
Elevator 2		
Fall arrest device 1		
Fall arrest device 2		
Electric cabinet		
	Elevator / Fall arrest device 1	Elevator / Fall arrest device 2
Wire rope (work)	(1) Length:	(3) Length:
Wire rope (safety)	(2) Length:	(4) Length:

Ref.	Description	Compliance	NOT Compliance		Comments
			Repairable	NOT repairable	
1	Platform				
1.1	Clean up				
1.2	Welds				
1.3	Handrails				
1.4	Floor panels				
1.5	Limit switch sensor				
1.6	End fixed disk				
2	Elevator 1				
2.1	Clean up				
2.2	Crankcase				
2.3	Connection box				
2.4	Functioning of brakes				
2.5	Noise				
2.6	Vibrations				
2.7	Fixing screws				
2.8	Plug				
3	Elevator 2				
3.1	Clean up				
3.2	Crankcase				

Ref.	Description	Compliance	NOT Compliance		Comments
			Repairable	NOT repairable	
3.3	Connection box				
3.4	Functioning of brakes				
3.5	Noise				
3.6	Vibrations				
3.7	Fixing screws				
3.8	Plus				
4	Fall arrest device 1				
4.1	Clean up				
4.2	Emergency stop				
5	Fall arrest device 2				
5.1	Clean up				
5.2	Emergency stop				
6	Electric cabinet				
6.1	Emergency stop				
6.2	Limit switch sensor				
7	Wire rope (1)				
7.1	Diameter				
7.2	Hook and locking				
7.3	Wear				
7.4	Broken threads				
7.5	End				
8	Wire rope (2)				
8.1	Diameter				
8.2	Hook and locking				
8.3	Wear				
8.4	Broken threads				
8.5	End				
9	Wire rope (3)				
9.1	Diameter				
9.2	Hook and locking				
9.3	Wear				
9.4	Broken threads				
9.5	End				
10	Wire rope (4)				
10.1	Diameter				
10.2	Hook and locking				
10.3	Wear				
10.4	Broken threads				
10.5	End				

Ref.	Description	Compliance	NOT Compliance		Comments
			Repairable	NOT Repairable	
11	Electric hoses				
11.1	Plugs and connections				
11.2	Cut				
11.3	Junction				
11.4	Mountings				
11.5	Proper section				

**In case of detecting one or more not compliance points, the platform must be immobilized and prevented from being used until the detected defects are solved.**

**The elevators, the fall arrest systems and electric cabinet must be checked by Accesus once a year.**







C/Energia 54  
08940 Cornellà de Llobregat (Barcelona)  
Telf.: (+34) 93 475 17 73  
[www.accessus.es](http://www.accessus.es)  
[accessus@accessus.es](mailto:accessus@accessus.es)